




QUICK REFERENCE GUIDE

Only install unit according to the supplied Installation Instructions.
When plugging unit in, always press the **RESET** button on the Current Device.



To Get Cool

1. Press On/Off button
2. Press Mode to select Cool
3. Press Fan Speed to choose speed
(Fan runs continuously)



To Get Warm

1. Press On/Off button
2. Press Mode to select Heat
3. Press Fan Speed to choose speed (Except 115V models which are low speed only)



To Save Energy

Press Mode to select Energy Saver
Cooling will turn off once the set temperature is reached. Every 10 minutes fan will run so room temperature can be sensed.



To Run Fan Only

Press Mode to select Fan Only
Fan will circulate air inside the room without air conditioned cooling.



To Compensate for Opening Doors

Press Fan Speed button to increase fan speed.
You may also select Auto Fan, which will speed up or slow down fan speed based on significant changes in room temperature.



To Go to Sleep

Press the Sleep button
Temperature increases 4°F over 1 hour and then holds this elevated setting for 7 hours.



To Enter Timer Start or Timer Stop

Press the Timer button
Timer button is functional when On/Off button is set to either On or Off.
Enter up to 24 hours for automatic turn on or shut off. When unit is On, the value entered is the time that the unit will shut off. When unit is Off, the value entered is the time that the unit will turn on.



To Clean the Air Filter

After 250 hours of use the Filter Reset light will illuminate to remind you to clean air filter. Press Filter Reset for 3 seconds to turn off light.

Remember:

Your Use & Care Guide has complete descriptions of all these features and more. Please read it carefully and keep in a safe place.